

For the perfect protection (after installation) - Admonter FLOORLINER

Appropriate and effective protection for covering the floor after installation.

Installation should only be done after all other interior works are finished (painging, tiles etc.) If this is not possible, we recommend to use Admonter Floorliner in order to avoid that the floor gets damaged or dirty. If the floor has been recently oiled Floorliner should be layed after 72 hours to the floor has enough time to dry. If this is not possible the Floorliner should be removed after work is done or overnight to ensure a quick and ordinary drying of the surface.

- high quality fleece (Thickness: 2mm, Width: 1m, 50m²/roll), with Admonter Logo
- prevents mechanical damages
- protects the floor of colour splashes and similar
- Vapour diffusive (14g/m²/d)
- free of radical materials
- backing with anti-slip surface
- friendly to environment, usable for several times



October 2017

Admonter
Holzindustrie AG

8911 Admont / Austria, Sägestraße 539

phone: +43(0)3613/3350-0, fax: +43(0)3613/3350-119, e-mail: info@admonter.at

FN237499p (LG Leoben) Gerichtsstand Liezen, UID-Nr.: ATU57198366

Bankverbindung: Raiffeisenbank Admont, IBAN: AT88 3800 1000 0002 7276, BIC: RZSTAT2G001

